

Electrogovernor Use:

- Lightbar Master switch (in cab) must be on.
- Manual Mode: no minimum pressure.
Expect 3 second response delay.
- Automatic Mode: 60 psi manifold pressure.
minimum. Above 100 psi expect 6 sec delay
and 5 psi steps.
- Not recommended for use with CAFS.
- Pressure sensor is near relief valve: flush
often.